


## MOTORIZED CELLULAR SHADE MANUAL



(MCS1-A for 36W AC Adapter &amp; DC Low Voltage Hard Wire)

(MCS1-A for 65W AC Adapter)

(MCS1-B for Battery)

NO.	Item	Specification
1	Power Source	MCS1-A: AC Adapter MCS1-A:DC Low Voltage Hard Wire MCS1-B: Li-ion Battery
2	Input	MCS1-A: 100-240V, 50/60Hz(AC Adapter) MCS1-A: 12V or 24V, 2A Max (DC Low Voltage Hard Wire) MCS1-B: 24V, 1.5A Max
3	Output	MCS1-A: 24V, 1.32A Max. MCS1-B: 10.89V, 1.65A Max.
4	Radio type	2.4G RF
5	Motor type	Brush DC motor
6	Charging type	Power Charger PB-01S Power Charger PB-02
7	Charging Time	< 2 hours
8	Charging Temperature	5°C ~ 35°C / 41°F ~ 95°F
9	Operating Temperature	0°C ~ 40°C / 32°F ~ 104°F
10	Relative Humidity	0% ~ 90% (Non-condensing)

FCC ID: Q3V-MCS1



IC ID: 28542-MCS1

CAN ICES-003 (B) / NMB-003(B)

## READ BEFORE INSTALLATION


**WARNING!** Important safety instructions. Follow all instructions since incorrect installation can lead to severe injury. Before installing the device, remove any unnecessary cords or components and disable any equipment not needed for powered operation.

**WARNING!** The installation height will vary according to product type or installation situation and may exceed 98.43" (2.5m).

**WARNING!** For the shades powered by battery (MCS1-B), please turn on the shade **AFTER** installation. Press and hold the shade button for 3 seconds, and the green light will flash, which means the shade is powered on.

### Reserve space before installation :

For Model# MCS1-A : Make sure to provide proper accessibility to an electrical outlet.



**IMPORTANT!** Wiring and servicing of these products should be referred to qualified personnel.

For **65W adapter** only. To direct wire, the plug can be removed by a licensed electrician.




Wiring Spec: 3 wire, 14-17AWG, 1.7 Amps at peak load. Wire function please reference below:

Function	Color
Live wire	Brown
Neutral wire	Blue
Earth ground	Green+Yellow

For Model# MCS1-B : with built-in Li-ion battery pack and charging accessories.

**IMPORTANT!** For Model #MCS1-B with built in Li-ion battery pack, please mount the headrail correctly. Make sure the headrail is level and that it doesn't tilt forward. Improper installation may cause the charging wand to not make full contact with the charging port. The shade installation only allows up to 3° of deflection tolerance.



## TOOLS YOU WILL NEED

- Level
- Measuring Tape
- Pencil
- Power Drill (6mm hex driver and drill bit)
- Screwdriver



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	Screws (Provided)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)

## GETTING STARTED

Check Standard Components/Hardware:


Installation Bracket



Installation Bracket Screw




Spacer (Optional)

With Spacer Block  
Hold Down Bracket (Optional) & Its ScrewShallow Mounting  
Remote Holder




### Hardware Standard Quantity:

Order Width (X)	Less or Equal to 64"	Between 64-1/8" and 112"	Over 112"
Installation Bracket	2	3	4
Installation Bracket Screw	4	6	8
Spacer Block (Optional)	Varies per order request: 1pc / bracket or 2pcs/bracket		
Hold Down Bracket (Optional)	2	2	2
Hold Down Bracket Screw (Optional)	2	2	2

### Check Components for MCS1-A for AC Adapter:





36W AC Adapter

6.6 ft. Extension Cable (Optional)  
(for 36W adapter)6 ft. Power Cable  
(for 65W adapter)DC Connection Harness  
(for Power Panel)

### Check Components for MCS1-B for Battery:

Charging Wand (Optional)

Wireless (with Rechargeable Battery)  
/Model#PB-01SWired (without Rechargeable Battery)  
/Model#PB-02


## MOUNTING INSTALLATION BRACKETS

The installation bracket may be used for **INSIDE** or **OUTSIDE** mounts.

**Please always avoid the charging port when placing the brackets. Mounting the brackets level is essential for proper operation of the shade.**


Shim the brackets if necessary to achieve a level alignment. The bracket requirements and placement are the same for inside and outside mount.

Measure 8" from both ends of the headrail. Mark the bracket location on the mounting surface. Proper alignment of brackets will make installation easier.




### Inside Mount:

Allow a minimum of 1/16" distance from the front of brackets to the edge of window opening as shown in the drawing on the right. Use two installation screws to secure brackets. Use wall anchors for drywall or plaster wall.




\* For shallow mounting, use 2 flat head screws to secure the bracket as shown in the drawing on the right.




### Outside Mount:

Use 2 flat head screws to secure each bracket. Use wall anchors for drywall or plaster wall.




Note: If spacer block is provided, please follow this guide:

Please always make sure the raised side of the spacer block is against the bracket.



### Install the Shade:

Position the head rail at an angle so that it is hooked to the front of the bracket. Then push it upward at the back to snap into the bracket.




Note: You will hear a click sound once the head rail is properly secured.

### Install Hold Down Bracket (Optional):


#### A. For Hold Down Brackets.

Use screw to secure each bracket. Please fasten the screw tightly.



### B. For Magnetic Hold Down


Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.




## Remote Holder Installation

### A. Plaster Wall (Use Installation Screws)

1. Place the remote holder at desired location, and use the pencil to mark the locations of the screws.



2. Place the remote holder against the wall and use two installation screws to secure the remote holder.




### B. Smooth Wall (Marble Wall, Quartz Wall, Glass - Use Adhesive Sticker)

For hard surfaces, such as marble, quartz, etc. it is recommended to use the double-sided foam tape provided.

## REMOVING THE SHADE

Fully raise the shade, and then gently remove the bracket off the headrail with a flat screwdriver.



## Congratulations!

You have finished installing the product.


Please also note that for shades with rechargeable batteries, the batteries will come with enough power to test your shade immediately after installation.

Rechargeable batteries will be shipped out with approximately 50% battery to allow for testing. However, it is recommended to charge your battery to full before using your shade for other purposes. To check the battery level, please refer to the power charger manual.

## Optional Parts Installation

### Side Mount Bracket

Side mount bracket is only available for the arch window with shade width  $\leq 37"$  and the normal bracket qty should be 2.




Side Mount Supporting Bracket




M4 Nut & Bolt



1 1/4" Screw



### Light Guard




Clear Plastic Tape (only for split light guard)

### How to assemble side mount bracket

Align the side mount supporting bracket holes with the installation bracket holes, and then screw the M4 nut & bolt into the diagonal holes for the left side mount bracket. Do the same for the right side mount bracket.



For 3/8"S, 9/16"S, 3/4"S, 1/2"D, 3/4"D & 1 1/4"S  
Motorized/ Motorized Day & Night



### Install Light Guard (optional for IB)

Notice: To avoid scraping, leave at least 1/16" (2mm) gap between fabric stack and light guard.  
The light guard is to be placed at back of the shade on left & right side.


A. When the light guard length  $\leq 96"$ , place the light guard vertically towards the bottom window frame and then mark out the location with a pencil. Remove the double sided tapes and carefully paste the light guard in position. Fix 2pcs of 3/4" flat head screws to secure the light guard.




Note: We recommend that the seam be placed on top, shown in above drawings.

### Extension Pole for Wireless (with Battery) Charging Wand (Power Charger PB-01S)


Step 1: Remove the Protective Sleeve.




Step 2: Loosen the clamp on Extension Pole.



Step 3: Connect Charging Wand(Power Charger) with Extension Pole.




Step 4: Tighten the clamp.




### Extension Pole for Wired (without Battery) Charging Wand (Power Charger PB-02)


Step 1: Remove the Protective Sleeve.




Step 2: Loosen the clamp on Extension Pole.




Step 3: Thread the cable through the hole on Extension Pole and connect the Charging Wand(Power Charger) with Extension Pole.



Step 4: Tighten the clamp.





## MOTORIZED CELLULAR SHADE MANUAL

## Catalogue

• SAFETY PRECAUTIONS .....	4
• HOW TO CHECK THE POWER CAPACITY.....	4
• CHARGE THE SHADE (MCS1-B) .....	5
• SHADE OPERATION .....	5
• HONEYCOMB MOTORIZATION - TROUBLESHOOTING .....	6
• TROUBLESHOOTING .....	6
• SAFETY STATEMENT.....	7
• SAFETY INSTRUCTIONS FOR LITHIUM BATTERY.....	7

## SAFETY PRECAUTIONS

Thank you for your purchase. Please read the instructions carefully before using the product, and save these instructions for future consultation.

- **WARNING!** Important safety instruction: It is critical for your safety and the safety of those around you to follow these instructions. Save these instructions.
- **WARNING!** The device shall be disconnected from its power source during cleaning, maintenance and when replacing parts.
- The products may contain Lithium-ion batteries; the battery contains flammable materials such as organic solvents. Please read the Important Safety Precautions before using the product.
- Please recharge the batteries every 3-6 months to ensure optimal performance of batteries.
- Product operation is intended for temperatures between 0°C/32°F ~40°C/104°F.
- Please note that the limited warranty will be voided if the product is modified, dismantled or used in any manner other than its intended purpose.
- The accessories, including Power Charger, Remote Control, Hub, and Repeater are designed to be used with : authorized Motorized Shades.
- **DO NOT** use them for any other purpose.
- Please make sure the shade route is clear when operating to avoid danger or damage.
- In order to improve the user experience and functionality, the firmware and software of this product will automatically update from time to time. (When the Hub is installed)
- **WARNING!** For the purposes of recharging the battery, only use the detachable supply unit provided with this appliance( UHVUU3036-240015SA : MX36W1-2401500U).
- **DO NOT** disassemble the products or any of their components. They do not contain serviceable parts. Servicing of these products should be referred to qualified personnel.
- This appliance contains batteries that are only replaceable by skilled personnel, trained authorized retailer or electrician.
- **DO NOT** operate the product with wet hands to avoid risk of electrical shock. The product needs to be powered off and disconnected from its power source during cleaning, maintenance and/or replacing parts.
- **DO NOT** operate the shade or swing the Power Charger while charging.
- The product is not to be used by persons such as children, those with reduced physical, sensory or mental capabilities, or those who lack experience and knowledge of the product, unless they have been given supervision or instruction. Children should be advised not to play with the products.
- **DO NOT** allow children to play with fixed controls. Keep remote controls away from children. Frequently examine the installation for imbalance, signs of wear or damage to cables, springs and fixings.
- **DO NOT** use if repair or adjustment is necessary.
- **DO NOT** operate when maintenance, such as window cleaning, is being carried out in the vicinity.
- **IMPORTANT:** Please reserve space for connecting the Power Charger while installing the shade, please refer to "Read Before Installation" Section for more information.


## HOW TO CHECK THE POWER CAPACITY

- There is at least 50% of power in shade and charging wand Li-ion battery for try function before shipping.
- Please find section "SHADE OPERATION" and "CHAGE THE SAHDE (MCS1-B)" for try function.
- Please insert the wireless or wired power charger in shade charging port to check the shade Li-ion battery capacity. Please reference below Defination of light Indicators.
- Please plug the 36W AC adapter to check wireless or wired power charger Li-ion battery capacity. Please reference below Defination of light Indicators.
- If you buy wired power charger, remember to plug the 36W AC adapter on power charger before charging the shade.

### There are two types of charging wand

Power Charger: (PB-01S)  
Wireless (with battery) Charging Wand  
(with 2 light indicators)

Power Charger: (PB-02)  
Wired (with no battery) Charging Wand  
(with 1 light indicator)



### Definitions of light Indicators


light Indicator	Battery Capacity	light Display
Power Meter for Shade Battery	Less than 50%	Green light flashes once every 2 seconds.
	50-75%	Green light flashes twice every 2 seconds.
	75%-90%	Green light flashes three times every 2 seconds.
	Over 90%	Green light illuminates steadily without flashing
	Fault / Poor Connection	Red light. Please refer to "Troubleshooting" for further information.
Power Meter for Power Charger (PB-01S)	Less than 50%	Green light flashes once every 2 seconds.
	50-75%	Green light flashes twice every 2 seconds.
	75%-90%	Green light flashes three times every 2 seconds.
	Over 90%	Green light illuminates steadily without flashing.
	Fault / Poor Connection	Red Light. Please refer to "Troubleshooting" for further information.

## CHARGE THE SHADE (MCS1-B)

### ⚠ WARNING!


- Please **DO NOT** operate the shade or swing the Power Charger while charging.
- Please recharge your shade every 3-6 months to ensure optimal performance of batteries.
- Please only use the 36W AC Adapter included with this product. If using the extension cable, please **DO NOT** bend or twist the cable to avoid product damage or raise safety concerns.
- Please charge the shade before use!
- For Power Charger(PB-01S), please **DO NOT** use it to charge the shade while it is being charged/plugged into the outlet.

### Charge the Shade by Power Charger (PB-01 with Battery)



After charging, please recharge Power charger (PB-01S) for next use.

### Charge the Shade by Power Charger (PB-02 without Battery)



**⚠ WARNING! DO NOT** release the power charger from your hand until it's inserted securely to avoid damage or personal injury caused by falling.

After charging, please store the 36W AC Adapter, Extension Cables, Power Charger and other accessories for later use.


## SHADE OPERATION

For Shade model# **MCS1-A** for AC Adapter: the shade will power on as soon as the power is connected.

For Shade model# **MCS1-B** for Battery:


Press and hold the shade button for 3 seconds and the green light will flash for power on before operation.

Press and hold the shade button for 3 seconds and the red light will flash for power off when necessary.




### 1. Operate the Shade by Remote Control:


Select the group of the shade, press OPEN to move shade to fully open.



Select the group of the shade, press CLOSE to move shade to fully closed.



Select the group of the shade, press ▲ or ▼ to adjust shade location.



■ : Stop the shade   ▲ : Move to Best View   ⌂ : Move to Best Privacy   ⭐ : Move to My Favorite

### 2. Single Tap Control to Operate the Shade:

When remote is out of reach, the shade can be operated by Single Tap function.



Gently lift bottom rail to move the shade downwards when the shade is still.

Gently lift bottom rail to stop the shade while the shade is in motion.


Gently lift bottom rail again to move the shade upwards.

**Single Tap function needs space to be activated. If there is no gap between window sill and bottom rail, please raise the shade a little, then try Single Tap.**

### 3. Operate the Shade by Shade Button:

When remote is out of reach, the shade can be operated by Shade Button.

Press the shade button to lower down the shade when the shade is still.  
Press the shade button to stop the shade while the shade is in motion.  
Press the button again to raise up the shade.



## HONEYCOMB MOTORIZATION - TROUBLESHOOTING

Before you start processing the troubleshooting, please check below few points first.

1. Make sure the shade is turned on.  
Shade with Li-ion battery need to press the shade button 3 seconds (and indicator light will flash in green) to turn on the shade.  
Shade with adapter will turn on once the adapter is plug on.
2. Make sure both upper and lower limits are set up successfully.  
The upper / lower limit are usually pre-set up in factory before shipment. Lost of limits may disabled some function of the shade.  
Press below buttons one by one on remote to check whether the upper / lower limit set is existing.

 : Best Privacy

 : Best View

 : My Favorite

If the shade does not react, please reset limits first, then try the failed operation again to see if the problem was resolved or not.  
If not, please go to the following pages.

## TROUBLESHOOTING

Problems	Possible Cause	Description
No reaction upon operation	No Signal	Operate the shade by a remote and check the light indicator on the shade. Green light blinks: The shade receives signal normally. Red light blinks: Low battery / Over temperature limit Red/Green light blinks: Other problems No light: Not receiving signal / Not paired with a remote / The shade is powered OFF.
	Low battery of remote	Please check the remote group lights works normally, or replace new batteries.
	Low battery of shade, model#MCS1-B	Please use power charger to charge the shade.
	The shade is not paired with the remote	Press and hold the paired group button, and check if the shade responds. Shade response as shiftx1 means it has been paired. Shade no response means it need to be paired first. Please refer to "Remote Control Manual" for pair steps.
	Exposure to High Temperatures	The shade might be overheated when the LED indicator on shade blinks red during operation. Please wait at least 30 minutes and operate the shade again. Please refer to the specification for applicable operating temperature.
	The limits are not fully setup.	Press  /  on remote to operate the shade and check if the shade light blinks green and the shade works normally. If not, the shade limits might not be fully set up for full functionality, please refer to "Remote Control Manual" to set up shade limits again. <b>IMPORTANT!</b> Top and Bottom limits must be setup for full function of the shades.
Limits Shift	Other Problems	Step.1 Re-turn on the shade, check the shade could move functionally. Step.2 Reboot the hardware: Press the shade button for 10 seconds till the red light illuminate. When the hardware finish rebooting, the signal will flash green light. Step.3 confirm the shade could move functionally. If not, please continue below procedures. Step.5 Clear upper / lower limit, make sure the button OPEN/CLOSE on remote are functional, and reset upper/lower limit.
	Abnormal power failure	Abnormal power failure may cause a shift of limits, please refer to "Remote Control Manual" to set up limits again.
Uneven Bottom Rail	Others	Please contact customer service for further assistance.
	It may be caused by many factors, such as uneven cords, uneven operation force and etc...	Use remote to fully open and close the shade several times until the shade back to level.
Shade moving in the opposite direction as the remote arrows	The cord reverse rolling on the spool	Step 1 - Clear lower limit. Step 2 - Press and release the OPEN button on the remote Step 3 - The shade will go down first, once the cord is completely released then the shade will change to go up. Step 4 - When the shade begins to move upward, press the STOP button on the remote Step 5 - Set lower limit. Step 6 - Use the remote buttons to confirm the shade direction has been corrected.

## SAFETY STATEMENT

### Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer / installer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### Industry Canada Equipment Standard for Digital Equipment (ICES) –Canada

This Class B digital apparatus complies with Canadian ICES-003.

### CAN ICES-3 (B)/NMB-3(B)

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

### Innovation, Science and Economic Development

#### Canada(ISED) Compliance Statement

This device complies with ISED's licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d' ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

## SAFETY INSTRUCTIONS FOR LITHIUM BATTERY

**The product may contain lithium-ion batteries; the battery contains flammable materials, such as organic solvents. Mishandling of the battery may cause fire, smoke, or explosion.**

#### ▲ DANGER

**Do not immerse the battery in any liquid, such as water, beverages, or other fluids.**

Exposure to liquid may damage the battery or the battery pack. Damaging the battery may generate heat, smoke, catch fire, or explode.

**Do not use or place the battery in or near an open flame, heater or high temperature areas (above 80°C or 176°F), such as those near a microwave or other cooking appliance.**

Subjecting the battery to high temperature or near electromagnetic radiation may damage the polyolefin separator and can cause short circuit. This may cause the battery to generate heat, smoke, catch fire, or explode.

#### **About Charging: Do not use unauthorized chargers.**

Only charge the battery within recommended conditions (e.g., temperature range, voltage, and current). Use of an unauthorized charger could cause the battery to generate heat, smoke, catch fire, or explode.

#### **Do not attach or insert battery with polarity reversed.**

If the battery does not easily fit into the charger or device, check the battery orientation. Do not force the battery into the compartment. If the battery is inserted incorrectly, the battery may generate heat, smoke, catch fire, or explode.

#### **Do not connect the battery to an AC outlet or DC automotive plug.**

The battery requires a specific charger. If the battery is connected directly to a power outlet, the battery may generate heat, smoke, catch fire, or explode.

#### **Do not use the battery in equipment for which it was not intended.**

If the battery is used in unapproved applications or systems, the battery may be damaged and generate heat, smoke, catch fire, or explode.

#### **Keep the battery away from heat and fire.**

Excessive heat will damage the battery and may cause it to generate smoke, catch fire, or explode.

**Do Not** connect the positive (+) and negative (-) terminals with a conductive material. Do not carry or store the battery with any metal objects. If the battery is shorted, it may overheat and the battery may generate heat, smoke, catch fire, or explode.

#### **Avoid excessive impact to the battery.**

Impact beyond specification may damage the battery. This may cause the battery to leak, generate heat, smoke, catch fire, or explode.

#### **Do not penetrate the battery with any sharp object.**

If subjected to a hard strike or penetrated by an object, the battery may be damaged, thereby causing the battery to short-circuit. This may cause the battery to generate heat, smoke, catch fire, or explode.

#### **Do not directly solder to the battery.**

Soldering directly to the battery could melt the separator, damage the fume release vent or other safety mechanisms. This may cause the battery to generate heat, smoke, catch fire, or explode.

#### **Do not disassemble the battery.**

Disassembly or modification of the battery may damage the protection circuit. This may cause the battery to generate heat, smoke, catch fire, or explode.

#### **Do not charge the battery near high temperature.**

If the battery is charged while exposed to high temperature, the battery's protection circuit may activate and prevent charging, or fail and cause the battery to generate heat, smoke, catch fire, or explode.

#### ▲ WARNING

##### Ingestion

Keep away from small children.

Keep the battery away from small children. If the battery or any of its component parts is swallowed, seek medical attention immediately.

#### Mixed Use

Do not mix with other batteries.

The battery should not be used with other batteries having a different capacity, chemistry, or manufacturer. Doing so could cause the battery to generate heat, smoke, catch fire, or explode.

#### Rust, Discoloration and Deformities

Do not use abnormal batteries.

Immediately stop using the battery if there are noticeable abnormalities, such as smell, heat, discoloration, or deformity. The battery may be defective and could generate heat, smoke, catch fire, or explode with continued use.

#### Charging Time

Stop charging if the charging process cannot be finished. If the battery cannot finish the charging process within the specified time, halt the charging process. The battery may generate heat, smoke, catch fire, or explode.

#### Leakage -1

Do not use a leaking battery near open flame.

If the battery or liquid leaking from the battery has an irritating odor, the battery should be kept away from any open flame. If exposed to an open flame, the battery could ignite and explode.

#### Leakage -2

Do not touch a leaking battery.

If liquid leaking from the battery gets into your eyes or makes contact with your skin, immediately flush your eyes or skin with clean water and seek medical attention. If left untreated, it will cause significant eye or skin damage.

#### Transport

Pack the battery securely for transport.

To prevent short-circuit or damage during transport, securely pack the battery in a case or carton.

#### ▲ CAUTION Exposure to Direct Sunlight

Do not use or leave the battery in a location exposed to excessive heat, such as in direct sunlight or in a car. Doing so could cause the battery to generate heat, smoke, catch fire, or explode. It may also cause the battery's performance and life to deteriorate.

#### Use with other Equipment or Power

The battery pack has a protection circuit. Do not use the battery with other equipment or power as it may damage the protection circuit. If the protection circuit fails, the battery may generate heat, catch fire, smoke, or explode.

#### Charging Temperature Range

Only charge the battery between 5°C and 35°C. Charging outside of this temperature range may cause the battery to leak, generate heat, or result in serious damage. It may also cause the battery's performance and life to deteriorate.

#### Charging Method

Read the user's manual for proper product charging method.

#### First Time Usage

Please contact the supplier if the battery gives off an unusual odor, generates heat, or shows signs of rust prior to its initial use.

#### Flammable Materials

Do not charge or discharge near flammable materials. Doing so could result in fire.


#### Handling of Exposed Contacts or Conductors

If the battery pack has a system interface consisting of stripped lead wires or exposed contact plates, handle with due care. Temporarily insulate exposed contacts and conductors with an insulator such as polypropylene tape or polyvinylchloride tape. Failure to do so could result in an electrical shock; a short circuit causing the battery to generate heat, smoke, catch fire, or explode; or the combustion of other materials.

#### Recycling

When disposing of the battery, recycle it according to local rules and regulations.

## Catalogue



### MODE D'INSTALLATION POUR STORE ALVÉOLAIRE MOTORISÉ

• PRÉCAUTIONS DE SÉCURITÉ .....	9
• COMMENT VÉRIFIER LA CAPACITÉ DE LA BATTERIE .....	9
• CHARGER LE STORE (MCS1-B) .....	10
• FONCTIONNEMENT DU STORE .....	10
• NORMAN NID D'ABEILLE MOTORISÉ - DÉPANNAGE .....	11
• DÉPANNAGE .....	11
• DÉCLARATION DE SÉCURITÉ .....	12
• INSTRUCTIONS DE SÉCURITÉ POUR LA BATTERIE AU LITHIUM .....	12

## PRÉCAUTIONS DE SÉCURITÉ

Nous vous remercions pour votre achat. Veuillez lire attentivement les instructions avant d'utiliser le produit, et conserver ces instructions pour une consultation ultérieure.

- **AVERTISSEMENT!** Instructions de sécurité importantes. Il est essentiel pour votre sécurité et celle de votre entourage de suivre ces instructions. Conservez ces instructions.
- **AVERTISSEMENT!** L'appareil doit être déconnecté de sa source d'alimentation pendant le nettoyage, l'entretien et le remplacement de pièces.
- Les produits peuvent contenir des batteries lithium-ion; la batterie contient des matériaux inflammables tels que des solvants organiques. Veuillez lire les précautions de sécurité importantes avant d'utiliser le produit.
- Veuillez recharger les batteries tous les 3 à 6 mois pour garantir une performance optimale des batteries.
- Le fonctionnement du produit est prévu pour des températures comprises entre 0°C/32°F – 40°C/104°F.
- Veuillez noter que la garantie limitée sera annulée si le produit est modifié, démonté ou utilisé d'une manière autre que celle à laquelle il est destiné.
- Les accessoires, y compris le chargeur d'alimentation, la télécommande, le contrôleur et le répéteur, sont conçus pour être utilisés avec : les stores motorisés autorisés.
- **NE PAS** les utiliser à d'autres fins.
- Veuillez vous assurer que le chemin du store est dégagé lors de l'utilisation afin d'éviter tout danger ou dommage.
- Afin d'améliorer l'expérience utilisateur et la fonctionnalité, le micrologiciel et le logiciel de ce produit seront automatiquement mis à jour de temps en temps (lorsque le contrôleur est installé).
- **AVERTISSEMENT!** Pour recharger la batterie, utilisez uniquement le bloc d'alimentation amovible fourni avec cet appareil (UHVUU3036-240015SA).
- **NE PAS** démonter le chargeur d'alimentation, ni aucun de ses composants. Ils ne contiennent pas de pièces réparables. L'entretien de ces produits doit être confié à un personnel qualifié.
- Cet appareil contient des batteries qui ne peuvent être remplacées que par un personnel qualifié, un revendeur agréé ou un électricien.
- **NE PAS** utiliser le produit avec des mains mouillées pour éviter tout risque de choc électrique. Le produit doit être éteint et déconnecté de sa source d'alimentation pendant le nettoyage, l'entretien et le remplacement de pièces.
- **NE PAS** faire fonctionner le store ou balancer le chargeur d'alimentation pendant la charge.
- Le produit ne doit pas être utilisé par des personnes telles que les enfants, les personnes aux capacités physiques, sensorielles ou mentales réduites, ou celles qui manquent d'expérience et de connaissance du produit, à moins qu'elles n'aient reçu une surveillance ou des instructions. Il faut conseiller aux enfants de ne pas jouer avec les produits.
- **NE PAS** permettre aux enfants de jouer avec les commandes fixes. Gardez les télécommandes hors de portée des enfants. Examinez fréquemment l'installation pour vérifier qu'elle n'est pas déséquilibrée, qu'elle ne présente pas de signes d'usure ou d'endommagement des câbles, des ressorts et des fixations.
- **NE PAS** utiliser si une réparation ou un réglage est nécessaire.
- **NE PAS** faire fonctionner l'appareil lorsque des travaux d'entretien, comme le nettoyage des fenêtres, sont effectués à proximité.
- **IMPORTANT:** Veuillez réserver un espace pour le branchement du chargeur d'alimentation lors de l'installation du store, veuillez vous référer à la section "A lire avant l'installation" pour plus d'informations.

## COMMENT VÉRIFIER LA CAPACITÉ DE LA BATTERIE

- Il y a au moins 50 % d'énergie dans la batterie Li-ion du store et de la tige de charge pour effectuer un essai avant l'expédition.
- Veuillez vous référer à la section 'OPÉRATION DU STORE' et 'CHARGER LE STORE (MCS1-B)' pour effectuer un essai de fonctionnement.
- Veuillez insérer le chargeur d'alimentation sans fil ou filaire dans le port de charge du store pour vérifier la capacité de la batterie Li-ion du store. Veuillez vous référer à la définition ci-dessous des indicateurs lumineux.
- Veuillez brancher l'adaptateur secteur 36W pour vérifier la capacité de la batterie Li-ion du chargeur d'alimentation sans fil ou filaire. Veuillez vous référer à la définition ci-dessous des indicateurs lumineux.
- Si vous achetez un chargeur d'alimentation filaire, n'oubliez pas de brancher l'adaptateur secteur 36W sur le chargeur d'alimentation avant de charger le store.

### Il existe deux types de tiges de charge.

Chargeur (PB-01S)  
Tige de chargement sans fil (avec batterie)  
(avec 2 indicateurs lumineux)

Chargeur (PB-02)  
Filaire (sans batterie) Tige de chargement  
(avec 1 indicateur lumineux)



### Définitions des indicateurs lumineux


Indicateur lumineux	Capacité de la batterie	lumière Affichage
Mesureur d'énergie pour la batterie de store	Moins de 50%	La lumière verte clignote une fois toutes les 2 secondes.
	50-75%	La lumière verte clignote deux fois toutes les 2 secondes.
	75%-90%	La lumière verte clignote trois fois toutes les 2 secondes.
	Plus de 90%	La lumière verte s'allume régulièrement sans clignoter.
	Défaut/ mauvaise connexion	Lumière rouge. Veuillez vous reporter à la section "Dépannage" pour de plus amples informations.
	Compteur d'énergie pour le chargeur (PB-01S)	La lumière verte clignote une fois toutes les 2 secondes.
Compteur d'énergie pour le chargeur (PB-01S)	50-75%	La lumière verte clignote deux fois toutes les 2 secondes.
	75%-90%	La lumière verte clignote trois fois toutes les 2 secondes.
	Plus de 90%	La lumière verte s'allume régulièrement sans clignoter.
	Défaut/ mauvaise connexion	Lumière rouge. Veuillez vous reporter à la section "Dépannage" pour de plus amples informations.

## CHARGER LE STORE (MCS1-B)

### ▲ AVERTISSEMENT!


- Veuillez **NE PAS** faire fonctionner le store ni balancer le chargeur d'alimentation pendant la charge.
- Veuillez recharger votre store tous les 3 à 6 mois pour assurer des performances optimales des batteries.
- Veuillez utiliser uniquement l'adaptateur secteur 36W inclus avec ce produit. Si vous utilisez le câble d'extension, veuillez **NE PAS** plier ni tordre le câble pour éviter d'endommager le produit ou de soulever des préoccupations de sécurité.
- Veuillez charger le store avant utilisation!
- Pour le chargeur (PB-01S), veuillez **NE PAS** l'utiliser pour charger le store pendant qu'il est en cours de charge ou branché sur la prise.

### Chargez le Store avec le Chargeur d'alimentation (PB-01 avec Batterie)



Après la charge, veuillez recharger le Chargeur d'alimentation (PB-01S) pour une utilisation ultérieure.

### Chargez le Store avec le Chargeur d'alimentation (PB-02 sans batterie)



**▲ AVERTISSEMENT! NE RELÂCHEZ PAS** le chargeur d'alimentation de votre main tant qu'il n'est pas inséré en toute sécurité pour éviter tout dommage ou blessure personnelle causée par une chute.

Après la charge, veuillez ranger l'adaptateur secteur 36W, les câbles d'extension, le chargeur d'alimentation et les autres accessoires pour une utilisation ultérieure.

## FONCTIONNEMENT DU STORE

Pour le modèle de store # **MCS1-A** avec adaptateur secteur : le store s'allumera dès que l'alimentation sera connectée.

Pour le store modèle# **MCS1-B** pour la batterie :


Appuyez sur le bouton du store et maintenez-le enfoncé pendant 3 secondes. La lumière verte clignote pour indiquer que le store est sous tension avant de fonctionner.

Appuyez sur le bouton du store et maintenez-le enfoncé pendant 3 secondes. La lumière rouge clignote pour permettre d'éteindre le store si nécessaire.




### 1. Commandez le store par télécommande:


Sélectionnez le groupe du store, appuyez sur OUVRIR pour déplacer le store en position complètement ouverte.



Sélectionnez le groupe du store, appuyez sur Fermer pour déplacer le store en position complètement fermée.




Sélectionnez le groupe du store, appuyez sur ▲ ou ▼ pour régler l'emplacement du store.



■ : Arrêt du store ▲ : Déplacer pour La Meilleure Vue ■ : Déplacer pour La Vie Privée ★ : Déplacer pour mon favori

### 2. Une seule commande pour actionner le store:

Lorsque la télécommande est hors de portée, le store peut être commandé par la fonction Pression Unique.



Soulevez doucement le rail inférieur pour déplacer le store vers le bas lorsque le store est immobile.

Soulevez doucement le rail inférieur pour arrêter le store lorsque celui-ci est en mouvement.

Soulevez à nouveau doucement le rail inférieur pour déplacer le store vers le haut.

**La fonction Single Tap a besoin d'espace pour être activée. S'il n'y a pas d'espace entre le rebord de la fenêtre et le rail inférieur, veuillez relever un peu le store, puis essayez Single Tap.**


### 3. Commandez le store par le bouton de le store:

Lorsque la télécommande est hors de portée, le store peut être commandé par le bouton du store.

Appuyez sur le bouton du store pour faire descendre le store lorsque celui-ci est immobile.

Appuyez sur le bouton du store pour arrêter le store lorsqu'il est en mouvement.

Appuyez à nouveau sur le bouton pour faire monter le store.



## NORMAN NID D'ABEILLE MOTORISÉ - DÉPANNAGE

### Avant de commencer le dépannage, veuillez d'abord vérifier les points ci-dessous.

- Assurez-vous que le store est allumé.  
Les stores avec batterie Li-ion doivent appuyer sur le bouton du store pendant 3 secondes (et la lumière indicatrice clignotera en vert) pour allumer le store.  
Le store avec adaptateur s'allumera dès que l'adaptateur sera branché.
- Assurez-vous que les limites supérieure et inférieure sont réglées avec succès.  
Les limites supérieure et inférieure sont généralement pré-réglées en usine avant l'expédition. La perte des limites peut désactiver certaines fonctions du store.  
Appuyez sur les boutons ci-dessous l'un après l'autre sur la télécommande pour vérifier si les limites supérieure / inférieure sont déjà définies.

⌂ : La Vie Privée

▲ : La Meilleure Vue

☆ : Mon Préféré

Si le store ne réagit pas, veuillez d'abord réinitialiser les limites, puis réessayez l'opération échouée pour voir si le problème a été résolu ou non.

Sinon, veuillez vous rendre aux pages suivantes.

### DÉPANNAGE

Problèmes	Cause possible	Description
Aucune réaction pendant l'opération	Aucun signal	Faites fonctionner le store à l'aide d'une télécommande et vérifiez l'indicateur lumineux sur le store. Le voyant vert clignote: le store reçoit le signal normalement. La lumière rouge clignote: Batterie faible / Dépassement de la limite de température La lumière rouge/ La lumière verte clignote: Autres problèmes Pas de lumière : Ne reçoit pas de signal / N'est pas apparié avec une télécommande / Le store est éteint.
	Batterie faible de la télécommande	Veuillez vérifier que la télécommande fonctionne normalement, ou remplacer les batteries.
	Batterie faible du store, modèle# MCS1-B	Veuillez utiliser un chargeur d'alimentation pour charger le store.
	Le store n'est pas associé à la télécommande	Appuyez et maintenez le bouton de groupe apparié, et vérifiez si le store répond. La réponse du store comme shiftx1 signifie qu'il a été apparié. L'absence de réponse de l'écran signifie qu'il doit d'abord être apparié. Veuillez vous référer au "Manuel de la télécommande" pour les étapes d'appairage.
	Exposition à des températures élevées	Le store peut être en surchauffe lorsque le voyant DEL du store clignote en rouge pendant le fonctionnement. Attendez au moins 30 minutes et faites fonctionner le store à nouveau. Veuillez vous référer aux spécifications pour la température de fonctionnement applicable.
	Les limites ne sont pas bien installées.	Appuyez sur la touche ⌂/▲ de la télécommande pour faire fonctionner le store et vérifiez si le voyant du store clignote en vert et si le store fonctionne normalement. Si ce n'est pas le cas, il se peut que les limites du store ne soient pas entièrement réglées pour une fonctionnalité complète, veuillez vous référer au "Manuel de la télécommande" pour régler à nouveau les limites du store. <b>IMPORTANT!</b> Les limites supérieures et inférieures doivent être réglées pour que les stores fonctionnent pleinement.

### DÉPANNAGE

Problèmes	Cause possible	Description
Aucune réaction pendant l'opération	Autre problème	<p>Étape 1 : Allumez à nouveau le store et vérifiez s'il peut bouger de manière fonctionnelle.</p> <p>Étape 2 : Redémarrez le matériel : Appuyez sur le bouton du store pendant 10 secondes jusqu'à ce que la lumière rouge s'allume. Lorsque le matériel a terminé le redémarrage, le signal clignotera en vert.</p> <p>Étape 3 : Confirmez que le store peut bouger de manière fonctionnelle. Si ce n'est pas le cas, veuillez continuer avec les procédures ci-dessous.</p> <p>Étape 5 : Effacez la limite supérieure/inférieure, assurez-vous que les boutons OUVERT/FERMÉ sur la télécommande fonctionnent, et réinitialisez la limite supérieure/inférieure.</p>
Déplacement des limites	Coupure de courant anormale	Une coupure de courant anormale peut entraîner un décalage des limites, veuillez vous référer au "Manuel de la télécommande" pour redéfinir les limites.
	Autre	Veuillez contacter le service clientèle pour obtenir une aide supplémentaire.
Rail inférieur inégal	Cela peut être dû à de nombreux facteurs, tels que des cordons inégaux, une force de fonctionnement inégale, etc...	Utilisez la télécommande pour ouvrir et fermer complètement le store plusieurs fois jusqu'à ce que le store revienne au niveau.
L'ombre se déplace dans la direction opposée à celle des flèches distantes	Le cordon s'enroule en sens inverse sur la bobine	<p>Étape 1 - Réinitialiser la limite inférieure.</p> <p>Étape 2 - Appuyer brièvement sur le bouton OUVRIR de la télécommande.</p> <p>Étape 3 - Le store descendra d'abord. Une fois le cordon complètement relâché, il remontera.</p> <p>Étape 4 - Lorsque le store commence à monter, appuyer sur le bouton STOP de la télécommande.</p> <p>Étape 5 - Régler la limite inférieure.</p> <p>Étape 6 - Utiliser les boutons de la télécommande pour confirmer que la direction du store a été corrigée.</p>

## DÉCLARATION DE SÉCURITÉ

### Déclaration de la Federal Communication Commission sur les interférences

Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant causer un fonctionnement indésirable.

Cet équipement a été testé et déclaré conforme aux limites d'un appareil numérique de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre de l'énergie de fréquence radio et, s'il n'est pas installé et utilisé conformément aux instructions, peut causer des interférences nuisibles aux communications radio. Cependant, il n'y a aucune garantie que des interférences ne se produiront pas dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception de la radio ou de la télévision, ce qui peut être déterminé en éteignant et en allumant l'équipement, l'utilisateur est encouragé à essayer de corriger les interférences par l'une des mesures suivantes :

- Réorienter ou déplacer l'antenne de réception.
- Augmentez la distance entre l'équipement et le récepteur.
- Connectez l'équipement à une prise sur un circuit différent de celui auquel le récepteur est connecté.
- Consultez le revendeur / l'installateur ou un technicien radio/TV expérimenté pour obtenir de l'aide.

Avertissement de la FCC : Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler l'autorisation de l'utilisateur à utiliser cet équipement.

Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

### Norme d'équipement d'Industrie Canada pour l'équipement numérique (ICES) - Canada

Cet appareil numérique de classe B est conforme à la norme canadienne ICES-003.

### CAN ICES-3 (B)/NMB-3(B)

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

### Déclaration de conformité d'Innovation, Science et Développement économique Canada (ISED)

Le présent appareil est conforme aux CNR d' ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

## INSTRUCTIONS DE SÉCURITÉ POUR LA BATTERIE AU LITHIUM

**Le produit peut contenir des batteries lithium-ion; la batterie contient des matériaux inflammables tels que des solvants organiques. Une manipulation incorrecte de la batterie peut provoquer un incendie, de la fumée ou une explosion.**

#### ▲ DANGER

**Ne plongez pas la batterie dans un liquide, tel que de l'eau, des boissons ou d'autres fluides.**

L'exposition à un liquide peut endommager la batterie ou le bloc de batteries. L'endommagement de la batterie peut générer de la chaleur, de la fumée, un incendie ou une explosion.

**N'utilisez pas et ne placez pas la batterie à l'intérieur ou à proximité d'une flamme nue, d'un appareil de chauffage ou de zones à haute température (plus de 80°C ou 176°F), comme celles situées à proximité d'un micro-ondes ou d'un autre appareil de cuisson.**

L'exposition de la batterie à une température élevée ou à un rayonnement électromagnétique proche peut endommager le séparateur en polyoléfine et provoquer un court-circuit. La batterie peut alors générer de la chaleur, de la fumée, prendre feu ou exploser.

**À propos du chargement : N'utilisez pas de chargeurs non autorisés.**

Ne chargez la batterie que dans les conditions recommandées (par exemple, plage de température, tension et courant). L'utilisation d'un chargeur non autorisé peut provoquer un dégagement de chaleur, de la fumée, un incendie ou une explosion de la batterie.

**Ne pas fixer ou insérer la batterie avec une polarité inversée.**

Si la batterie ne s'insère pas facilement dans le chargeur ou l'appareil, vérifiez l'orientation de la batterie. Ne forcez pas la batterie dans le compartiment. Si la batterie est mal insérée, elle peut générer de la chaleur, de la fumée, prendre feu ou exploser.

**Ne connectez pas la batterie à une prise de courant alternatif ou à une prise automobile en courant continu.**

La batterie nécessite un chargeur spécifique. Si la batterie est connectée directement à une prise de courant, elle peut générer de la chaleur, de la fumée, prendre feu ou exploser.

**N'utilisez pas la batterie dans un équipement pour lequel elle n'a pas été conçue.**

Si la batterie est utilisée dans des applications ou des systèmes non approuvés, elle peut être endommagée et générer de la chaleur, de la fumée, prendre feu ou exploser.

**Conservez la batterie à l'abri de la chaleur et du feu.**

Une chaleur excessive endommagera la batterie et peut générer de la fumée, prendre feu ou exploser.

**Ne connectez pas les bornes positive (+) et négative (-) avec un matériau conducteur. Ne transportez pas et ne stockez pas la batterie avec des objets métalliques. Si la batterie est court-circuitée, elle risque de surchauffer et de générer de la chaleur, de la fumée, de prendre feu ou d'exploser.**

**Évitez les chocs excessifs sur la batterie.**

Un choc dépassant les spécifications peut endommager la batterie. Cela peut provoquer une fuite, un dégagement de chaleur, de la fumée, un incendie ou une explosion de la batterie.

**Ne pas pénétrer dans la batterie avec un objet pointu.**

Si elle est soumise à un choc violent ou pénétrée par un objet, la batterie peut être endommagée et provoquer un court-circuit. La batterie peut alors générer de la chaleur, de la fumée, prendre feu ou exploser.

**Ne pas souder directement sur la batterie.**

Le fait de souder directement sur la batterie pourrait faire fondre le séparateur, endommager l'évent de dégagement des fumées ou d'autres mécanismes de sécurité. La batterie pourrait alors générer de la chaleur, de la fumée, prendre feu ou exploser.

**Ne démontez pas la batterie.**

Le démontage ou la modification de la batterie peut endommager le circuit de protection. Cela peut entraîner un dégagement de chaleur, de la fumée, un incendie ou une explosion de la batterie.

**Ne chargez pas la batterie à proximité de températures élevées.**

Si la batterie est chargée alors qu'elle est exposée à des températures élevées, le circuit de protection de la batterie peut s'activer et empêcher la charge, ou échouer et faire en sorte que la batterie dégage de la chaleur, de la fumée, prenne feu ou explode.

#### ▲ AVERTISSEMENT

##### Ingestion

Tenir hors de portée des jeunes enfants.

Gardez la batterie hors de portée des jeunes enfants. En cas d'ingestion de la

batterie ou de l'un de ses composants, consultez immédiatement un médecin.

#### Utilisation mixte

Ne pas mélanger avec d'autres batteries.

La batterie ne doit pas être utilisée avec d'autres batteries ayant une capacité, une composition chimique ou un fabricant différents. Cela pourrait provoquer un dégagement de chaleur, de la fumée, un incendie ou une explosion de la batterie.

#### Rouille, décoloration et déformations

N'utilisez pas de batteries anormales.

Arrêtez immédiatement d'utiliser la batterie si elle présente des anomalies notables, telles qu'une odeur, une chaleur, une décoloration ou une déformation. La batterie peut être défectueuse et pourrait générer de la chaleur, de la fumée, prendre feu ou exploser si vous continuez à l'utiliser.

#### Temps de charge

Arrêtez la charge si le processus de charge ne peut pas être terminé.

Si la batterie ne peut pas terminer le processus de charge dans le temps imparti, arrêtez le processus de charge. La batterie peut générer de la chaleur, de la fumée, prendre feu ou exploser.

#### Fuite -1

N'utilisez pas une batterie qui fuit à proximité d'une flamme nue.

Si la batterie ou le liquide s'écoulant de la batterie a une odeur irritante, la batterie doit être éloignée de toute flamme nue. Si elle est exposée à une flamme nue, la batterie pourrait s'enflammer et exploser.

#### Fuite -2

Ne touchez pas une batterie qui fuit.

Si le liquide qui s'écoule de la batterie entre en contact avec vos yeux ou votre peau, rincez immédiatement vos yeux ou votre peau à l'eau claire et consultez un médecin. S'il n'est pas traité, il causera des dommages importants aux yeux ou à la peau.

#### Transport

Emballez la batterie en toute sécurité pour le transport.

Pour éviter tout court-circuit ou dommage pendant le transport, emballez solidement la batterie dans une caisse ou un carton.

#### ▲ ATTENTION

##### Exposition à la lumière directe du soleil

N'utilisez pas et ne laissez pas la batterie dans un endroit exposé à une chaleur excessive, par exemple en plein soleil ou dans une voiture. Cela pourrait entraîner un dégagement de chaleur, de la fumée, un incendie ou une explosion de la batterie. Les performances et la durée de vie de la batterie pourraient également se détériorer.

##### Utilisation avec d'autres équipements ou puissances

La batterie est dotée d'un circuit de protection. N'utilisez pas la batterie avec un autre équipement ou une autre alimentation, car cela pourrait endommager le circuit de protection. En cas de défaillance du circuit de protection, la batterie peut générer de la chaleur, prendre feu, fumer ou exploser.

##### Plage de température de charge

Ne chargez la batterie qu'entre 5°C et 35°C. Une charge en dehors de cette plage de température peut entraîner une fuite de la batterie, un dégagement de chaleur ou des dommages importants. Les performances et la durée de vie de la batterie peuvent également se détériorer.

##### Méthode de chargement

Lisez le manuel de l'utilisateur pour connaître la méthode de chargement appropriée du produit.

##### Première utilisation

Veuillez contacter le fournisseur si la batterie dégage une odeur inhabituelle, génère de la chaleur ou montre des signes de rouille avant sa première utilisation.

##### Matériaux inflammables

Ne pas charger ou décharger à proximité de matériaux inflammables. Cela pourrait provoquer un incendie.

##### Manipulation des contacts ou des conducteurs exposés

Si le bloc-batterie présente une interface système constituée de fils conducteurs dénudés ou de plaques de contact exposées, manipulez-le avec précaution. Isolez temporairement les contacts et les conducteurs exposés avec un isolant tel qu'un ruban de polypropylène ou de polychlorure de vinyle. Le non-respect de cette consigne peut provoquer un choc électrique, un court-circuit entraînant un dégagement de chaleur, de la fumée, un incendie ou une explosion de la batterie, ou la combustion d'autres matériaux.

##### Recyclage

Lorsque vous mettez la batterie au rebut, recyclez-la conformément aux règles et réglementations locales.